

**ELECTRICAL**

1. Exhibition Place voltages are 600/120/208 volts 3 phase. Please check with your technical coordinator to see if your machines are compatible with these voltages. If so, you will save on costs.
2. All other voltages are available from SHOWTECH with the use of a transformer. Transformers must be placed within your booth space so please allow for the transformer when you do your space plan/layout. Approximate size can be provided by SHOWTECH (see below for contact info).
3. Transformers will be required on 208 volt connections greater than 30 amps.
4. 600 volt connections do not require a transformer.
5. Exhibition Place does have floor ports (only in halls A,B,C,D in the ECC)
6. Power will be distributed by SHOWTECH from exterior walls, floor ports and cable drops from the ceiling.
7. If you have an Island booth, please indicate a main power drop location on SHOWTECH's Booth Layout Form and submit the form with your Electrical & Lighting Order Form. We will distribute under carpet outlets from that location.

Ontario's Electrical Safety Authority (ESA) requires that all machinery that will be displayed and/or powered up during an event must be approved by the ESA before show opening. Exhibitors are responsible to obtain "Permission to Show/Energize" from the ESA directly. SHOWTECH cannot apply or be responsible for this permission. To obtain the ESA "Permission to Show/Energize", go to <https://www.esasafe.com/consumers/permits-and-inspections/inspection-forms> to apply for permission/approval from the ESA. **Apply as soon as possible to avoid onsite complications.**

**MECHANICAL**

8. Compressed air pressure is approximately 110 PSI and available anywhere in the facility by ordering from SHOWTECH. Please use the SHOWTECH's Mechanical Order Form to order this service.
9. Exhibition Place does have floor ports (only in halls A,B,C,D in the ECC)
10. Air lines are distributed by SHOWTECH from exterior walls, dropped from the ceiling or from floor ports.
11. Only ½" air lines can be run under carpet in booths.
12. If you are in an island booth, please indicate a main air drop location on SHOWTECH's Booth Layout Form and submit with your Mechanical Order Form. SHOWTECH will distribute any under carpet requirements from that location.
13. Water pressure is approximately 50 PSI and available anywhere in the facility by ordering from SHOWTECH's Mechanical Order Form.
14. If you require hot water for your booth, an electric hot water tank will need to be installed by SHOWTECH within your booth space. Please plan accordingly and notify us in the Special Requirements space on the bottom of the SHOWTECH Mechanical Order Form or call for assistance (416.263.3594).
15. Natural gas is available in various locations within the facility. Please check with SHOWTECH (416.263.3594) or Show Management, as soon as possible, if you require Natural Gas.
16. Sanitary floor drains are located in various locations within the facility. Please check with SHOWTECH (416.263.3594) or Show Management, as soon as possible, if you require a drain connection.

**SHOWTECH POWER & LIGHTING contact information: 416.263.3594**